



Certification Label on Coated Fuel Tanks

BULLETIN

Models Affected: Certain 2017 Blue Bird Vision and All American with Optional Coated Fuel Tank

ISSUE

Fuel tank certification label may be covered by an applied coating. Label is required to be visible.

CORRECTIVE ACTION

Remove coating from fuel tank certification label in order that the label be visible.


PROCEDURE

WARNING: Always follow all Federal, State, Local and Shop safety standards and use proper safety equipment, and thoroughly read and understand all instructions before performing these procedures.

WARNING: Use eye protection and face shield while performing this procedure.

1. Park bus on level surface, turn off engine, remove key, and chock wheels.
2. Locate label on bottom of fuel tank between the front of the tank and drain plug.

VIEWED FROM BOTTOM OF BUS



S I 6 Y X
- S E R V I C E B U L L E T I N -




Certification Label on Coated Fuel Tanks

BULLETIN

3. Remove coating from the label with a lint free cloth and “Bug and Tar” remover until the entire label can be read.

Note: Obtain “Bug and Tar” remover locally.

4. Place bus back in service.



S I 6 Y X
- S E R V I C E B U L L E T I N -